



BCD 180 Knot Filler Gun

Handling & maintenance

Technical info

- Accepts Ø12 mm sticks
- Smaller tool
- Perfect for craftsmen / private use
- Pre-adjusted temperature 170 °C
- 80W
- Changeable nozzle
- Pre-heating approx. 7 min
- Lightweight model, 250 g
- Cord, approx. 1700 mm



The tool must be placed in a standing position.



Never place the heated tool on the side.



Never point the nozzle upwards.

Caution!

The hot nozzle can cause damage and/or burns. After use, allow the gun to cool down completely before storing it. Keep safely and out of reach of children.

► Handling

Please note the following handling points

- ✓ Let the gun heat for approx. 7 minutes
- ✓ Never pull a stick backwards from the gun!
- ✓ Never place the gun on the side or point it upwards!
- ✓ Use only recommended adhesives.
- ✓ Keep the melting chamber free of dirt and dust.
- ✓ Protect the device from moisture and liquids.

The perfect match

Knot Filler 150 mm

Compact bags with 8 pieces of Knot Filler sticks 150 mm are perfect for the BCD 180 Knot Filler gun. Comes in a variety of colors and two mixed bags.



Mix 1

Mix 2

► Claims

Important info regarding claims

When we dismantle a tool, we can see what caused the malfunction. In 99% of the cases, one of the below mentioned points has occurred - they are not valid reasons for a complaint.

If you are convinced that none of the points have occurred, we will gladly check the tool in our workshop.

The following errors are not valid reasons for complaint:

- The gun was placed on its side.
- The gun and nozzle were held upwards for too long.
- The gun was not heated enough before starting.
- A stick was pulled backwards from the gun.